


























RT-7700 SPARE PARTS

NO	PARTS NAME	set	picture
100	Cover Set	#101~104 Assembly	
101-1	Front Cover		
101-2	Main Cover		
101-3	Torsion Spring(LH)		
101-4	Torsion Spring(RH)		
101-5	Safty Plate Spring		
103	Knife Box Lever		
104	Coil Spring		
106	Switch Name Plate		
200B	Knife Box Set	#201~214 Assembly	
201B	Knife Box Set		
202	Upper Knife Safe Plate		
203	Coil Spring		
204	Oil Sponge		
205	Knife Support Rail(LH)		
206	Knife Support Rail(RH)		




RT-7700 SPARE PARTS

NO	PARTS NAME	set	picture
207	Bottom Knife		
208	Bottom Knife Pressing Plate(R)		
209	Bottom Knife Pressing Plate(L)		
210	Bottom Knife Torsion Spring		
211	Upper Knife		
212	Upper Knife Fix Plate Spring		
213	Cross Round Head Tapping Screw		
214	Tape Discharge Guide Plate Set		
300	Knife Gear Box Set	#301~327 Assembly	
301	Knife Gear Box Front		
302	Knife Gear Box Rear		
303	Tape Auto Sensor Set	#303-1~303-3 Ass'y	
304	Lower Knife Slide Plate		
305	Knife Cam Plate Roller		
306	Knife Sensor Lever		
307	Knife Cam Plate		












RT-7700 SPARE PARTS

NO	PARTS NAME	set	picture
308	Knife Cam Fix Bar LH		
309	Knife Cam Fix Bar RH		
310	Knife Motor Pinion		
311	Knife 1'st Gear		
312	Knife 2'nd Gear		
313	Knife 3'rd Gear		
314	Knife Main Gear		
315	Knife Gear Bearing		
316	Knife Gear Shaft		
317	Knife Motor		
318	Knife Motor Cable		
322	Innet Cable Shot		
323	Knife Sensor Set		
324	Coil Spring		
325	Knife Sensor Torsion Spring		
326	Knife Cam Plate Shaft		








RT-7700 SPARE PARTS

NO	PARTS NAME	set	picture
327	Cross Round Head screw		
400	Bottom Case Set		
401	Bottom Case		
402	Cushion Rubber(B)		
403	Cushion Rubber(A)		
404	Tape Wide Control Plate		
405	Tape Separating Plate		
406	Tape Separating Sub Plate		
407	Angle Plate		
409	Tape Guide Plate Set	#409-1~3Ass'y	
409-1	Tape Guide Plate (LH)		
409-2	Tape Guide Plate (RH)		
409-3	Tape Guide Post		
411	Tape Guide Shaft		
412	Oil Bottle		
413	Cross Round Head Screw		












RT-7700 SPARE PARTS

NO	PARTS NAME	set	picture
415	Innet - A		
416	Power Switch		
417	Innet Cable Long		
418	Power Board		
419	Drive Board		
420	Earth terminal		
421	Safety Cover		
422	24V Joint Cable		
423	9V Joint Cable		
424	Inlet 2P Cable		
500S (P)	Front Frame Set(PP)	#500A,500B, 528S(A) Assembly	
500S (S)	Front Frame Set(SI)	#500A,500B, 528S(B) Assembly	
500A	Front Frame(A) Set	#501A,502A 504~508,513~515, 519 Assembly	
500B	Front Frame(B) Set	#501B,502B,503, 511,512,520~527 Assembly	
501A	Front Frame LH		
501B	Front Frame LH		









RT-7700 SPARE PARTS

NO	PARTS NAME	set	picture
502A	Front Frame RH		
502B	Front Frame RH		
503A	Middle Roller		
504A	Rugged Roller Lower		
504B	Rugged Roller Lower *Option		
505A	Rugged Roller Upper		
505B	Rugged Roller Upper *Option		
506	Tape Guide Entrance		
507	Rugged Roller Bushing		
508	Rugged Roller Spring		
511	Middle Roller Gear		
512	2'nd Idle Gear		
513	Rugged roller Drive Gear		
514	Lower Rugged Gear		
515	Upper Rugged Gear		
519	Rugged Roller Lower Bush		












RT-7700 SPARE PARTS

NO	PARTS NAME	set	picture
520	Tape Check Plate		
521A	Large Pressing Roller ****option		
521B	Large Pressing Roller(B)		
522	Pressing Roller Gear		
523	Large Pressing Roller Bushing		
524	Coil Spring		
525	Spring Cap		
526	1'st Idle Gear		
527	Cross Round Head screw		
528B	Large Roller		
529	Large Roller Metal		
530	Rotating Gear		
531	Dubble Gear		
532	Trus Head Tapping Screw		
600	Main Frame Set	#601~632 Assembly	
601	Main Frame LH		


RT-7700 SPARE PARTS

NO	PARTS NAME	set	picture
602	Main Frame RH		
604	Tape Regulating Plate		
606	Brush		
608	Tape Support Roller A		
609B	Tape Security Pole		
610B	Tape Support Roller B		
611	Geared Motor		
611-1	Geared Motor Cable		
611-2	Motor seat		
612	Motor Gear		
617	Guide Plate Hanger		
618	Guide Plate Hanger Spring		
619	Tape Guide Set Pin		
623	Cross Flat Head Screw		
626	Tapping Screw		
627	Tape Guide Set Torsion Spring		

RT-7700 SPARE PARTS

NO	PARTS NAME	set	picture
628	Button PCB (A)		
	Tect Switch		
	LED		
629B	Side Frame PCB (B)		
630	Milli Senser		
631	Button PCB Cable		
632B	Side Frame PCB Cable 130mm		
700	Tape Guide Frame Set	#701~710 Assembly	
701	Tape Guide Frame (A)		
702	Tape Guide Frame (B)		
703	Guide Roller		
704	Braker Roller		
705	Braker (A)		
706	Braker (B)		
707	Curving Spring		
708	Guide Roller Shaft		

RT-7700 SPARE PARTS

NO	PARTS NAME	set	picture
709	Cross Round Head Screw		
710	Nut		
801	Power Cord		